



Firmware Release Note

P-202H Plus v2

Standard version

Release 3.40(AND.0)C0

Date: July 13, 2006
Author: Rongrong Guo

ZyXEL P-202H Plus v2 Standard Version release 3.40(AND.0)C0 Release Note

Date: July 13, 2006

Supported Platforms:

ZyXEL P-202H Plus v2

Versions:

ZyNOS F/W Version : V3.40(AND.0) | 07/13/2006 17:00:00
BootBase : V1.05 | 04/20/2004 10:36:26

Notes:

The P-202H Plus v2, is 3rd generation of ZyXEL ISDN product family. It is a ISDN router for small/medium office to have Internet access and LAN-to-LAN application through ISDN connection over the ISDN line.

Known Issues:

1. Remote management feature can be configured via SMT only.
2. If using Linux to access device via telnet and staying in menu 24.1 for a few hours, P202H will reboot.
3. P202H can't accept calls from Allied Telesyn AR-410 if authentication type of AR-410 is set to PAP/CHAP.
4. MSN audio function can't pass through if the firewall enable.
5. The Filter can not take effect on the IP Alias.

Features:

Modifications in V 3.40(AND.0) | 07/13/2006

1. Change to FCS version

Modifications in V 3.40(AND.0)b2 | 06/07/2006

1. [BUG FIXED] PPTP client in Lan PC can't dial to server in another Lan.
2. [BUG FIXED] In Italy switch, the router sometimes can't link up.

Modifications in V 3.40(AND.0)b1 | 05/23/2006

1.Create this project for P-202H Plus v2 standard version.

Annex A CI Command List

Command Class List Table		
System Related Command	Exit Command	Ethernet Related Command
IP Related Command	IPSec Related Command	

System Related Command

[Home](#)

Command			Description
sys			
callhist			
	display		display call history
	remove	<index>	remove entry from call history
countrycode		[countrycode]	set country code
domainname			display domain name
edit		<filename>	edit a text file
extraphnum			maintain extra phone numbers for outcalls
	add	<set 1-3> <1st phone num> [2nd phone num]	add extra phone numbers
	display		display extra phone numbers
	node	<num>	set all extend phone number to remote node <num>
	remove	<set 1-3>	remove extra phone numbers
	reset		reset flag and mask
feature			display feature bit
firewall			
	acl		
		disp	display specific ACL set # rule #, or all ACLs.
	active	<yes no>	active firewall or deactivate firewall
	clear		clear firewall log
	cnt		
		disp	display firewall log type and count.
		clear	clear firewall log count.
	disp		display firewall log
	online		set firewall log online.
	pktdump		dump the 64 bytes of dropped packet by firewall
	update		update firewall
	tcprst		
		rst	set TCP reset sending on/off.
		rst113	set TCP reset sending for port 113 on/off.
		display	display TCP reset sending setting.
	dos		
		smtp	set SMTP DoS defender on/off
		display	display SMTP DoS defender setting.
		ignore	set if firewall ignore DoS in lan/wan/dmz/wlan
	ignore		
		triangle	set if firewall ignore triangle route in lan/wan/dmz/wlan
hostname		[hostname]	display system hostname
log			
	clear		clear log error
	disp		display log error
	online	[on off]	turn on/off error log online display

ZyXEL Confidential

	stdio		[second]	change terminal timeout value
	trcdisp			monitor packets
	syslog			
		server	[destIP]	set syslog server IP address
		facility	<FacilityNo>	set syslog facility
		type	[type]	set/display syslog type flag
		mode	[on off]	set syslog mode
	version			display RAS code and driver version
	view		<filename>	view a text file
	wdog			
		switch	[on off]	set on/off wdog
		cnt	[value]	display watchdog counts value: 0-34463
	atsh			display MRD field
	socket			display system socket information
	filter			
		netbios		
			disp	display netbios filter status
			config <0:LAN to WAN, 1:WAN to LAN, 2:LAN to DMZ, 3:IPSec passthrough, 4:Trigger Dial> <on off>	config netbios filter
	ddns			
		debug	<level>	enable/disable ddns service
		display	<iface name>	display ddns information
		restart	<iface name>	restart ddns
		logout	<iface name>	logout ddns
	cpu			
		display		display CPU utilization

Exit Command

[Home](#)

Command			Description
exit			exit smt menu

Ethernet Related Command

[Home](#)

Command			Description
ether			
	config		display LAN configuration information
	driver		
		cnt	
		disp <name>	display ether driver counters
		status	<ch_name>
			see LAN status
	version		see ethernet device type

IP Related Command

[Home](#)

Command			Description
ip			
	address	[addr]	display host ip address
	alias	<iface>	alias iface
	aliasdis	<0 1>	disable alias
	arp		
		status	<iface>
	dhcp		<iface>
		client	
		release	release DHCP client IP
		renew	renew DHCP client IP

		mode	<server relay none client>	set dhcp mode
		relay	server <serverIP>	set dhcp relay server ip-addr
		reset		reset dhcp table
		server		
			probecount <num>	set dhcp probe count
			dnsserver <IP1> [IP2] [IP3]	set dns server ip-addr
			winsserver <winsIP1> [<winsIP2>]	set wins server ip-addr
			gateway <gatewayIP>	set gateway
			hostname <hostname>	set hostname
			initialize	fills in DHCP parameters and initializes (for PWC purposes)
			leasetime <period>	set dhcp leasetime
			netmask <netmask>	set dhcp netmask
			pool <startIP> <numIP>	set dhcp ip pool
			renewaltime <period>	set dhcp renew time
			rebindtime <period>	set dhcp rebind time
			reset	reset dhcp table
			server <serverIP>	set dhcp server ip for relay
			dnsorder [router isp]	set dhcp dns order
		status	[option]	show dhcp status
		static		
			delete <num> all	delete static dhcp mac table
			display	display static dhcp mac table
			update <num> <mac> <ip>	update static dhcp mac table
	dns			
		stats		
			clear	clear dns statistics
			disp	display dns statistics
	icmp			
		status		display icmp statistic counter
		discovery	<iface> [on off]	set icmp router discovery flag
	ifconfig		[iface] [ipaddr] [broadcast <addr> mtu <value> dynamic]	configure network interface
	ping		<hostid>	ping remote host
	route			
		status	[if]	display routing table
		add	<dest_addr default>[/<bits>] <gateway> [<metric>]	add route
		addiface	<dest_addr default>[/<bits>] <gateway> [<metric>]	add an entry to the routing table to iface
		addprivate	<dest_addr default>[/<bits>] <gateway> [<metric>]	add private route
	status			display ip statistic counters
	udp			
		status		display udp status
	tcp			
		status	[tcb] [<interval>]	display TCP statistic counters
	xparent			
		join	<iface1> [<iface2>]	join iface2 to iface1 group
		break	<iface>	break iface to leave ipxparent group

ipsec				
	debug	<1 0>		turn on off trace for IPsec debug information
	ipsec_log_disp			show IPSec log, same as menu 27.3
	route	lan	<on off>	After a packet is IPSec processed and will be sent to LAN side, this switch is to control if this packet can be applied IPSec again. Remark: Command available since 3.50(WA.3)
		wan	<on off>	After a packet is IPSec processed and will be sent to WAN side, this switch is to control if this packet can be applied IPSec again. Remark: Command available since 3.50(WA.3)
	show_runtime	sa		display runtime phase 1 and phase 2 SA information
		spd		When a dynamic rule accepts a request and a tunnel is established, a runtime SPD is created according to peer local IP address. This command is to show these runtime SPD.
	switch	<on off>		As long as there exists one active IPsec rule, all packets will run into IPsec process to check SPD. This switch is to control if a packet should do this. If it is turned on, even there exists active IPsec rules, packets will not run IPsec process.
	timer	chk_my_ip	<1~3600>	- Adjust timer to check if WAN IP in menu is changed - Interval is in seconds - Default is 10 seconds - 0 is not a valid value
		chk_conn.	<0~255>	- Adjust auto-timer to check if any IPsec connection has no traffic for certain period. If yes, system will disconnect it. - Interval is in minutes - Default is 2 minutes - 0 means never timeout
		update_peer	<0~255>	- Adjust auto-timer to update IPsec rules which use domain name as the secure gateway IP. - Interval is in minutes - Default is 30 minutes - 0 means never update Remark: Command available since 3.50(WA.3)
	updatePeerIp			Force system to update IPsec rules which use domain name as the secure gateway IP right away. Remark: Command available since 3.50(WA.3)
	dial	<rule #>		Initiate IPsec rule <#> from ZyWALL box Remark: Command available since 3.50(WA.3)
	display	<rule #>		Display IPsec rule #