



UP2000 DRILL TEMPLATE

NOTE:

ALL 6 "A" HOLES ON TEMPLATE MUST LINE UP WITH STANDARD ATX MOUNTING HOLES IN ATX CHASSIS.

8 "B" HOLES SHOULD BE ADDED TO ATX CHASSIS.